


Kangaroo™

KANGAROO OMNI™ Enteral Feeding Pump

Ouick Reference Guide





len –

1. Selection Buttons

Press a key to select the option that appears next to it on the screen.

2. Power Button

Press once to power on. Press and hold to power off.

3. Power Source


Shines a green light when the pump is connected to AC power.

4. Pump Status

- = Warning Alarm
- = Notice or Caution Alarm
- = Standby or Feeding



Set Up the Pump




1. Make sure the top of the fluid column is placed at 10 inches (25.4 cm) above the top of the pump.



2. Press Power button.



3. Select Clear Settings to enter new feed 4. Load Set. Insert from bottom and snap parameters. Select **Keep Settings** to keep old feed parameters.



into place.

Prime

If you selected Manual Prime:

reaches end of tubing.

MANUAL PRIME

Press and hold Prime Feed


until fluid reaches end of

When priming is complete.

press Done.

Prime the Pump






2. Select Priming Mode.



If you selected Auto Prime: 3. Wait for pump to finish priming.



3. When ready to begin feeding, select Start.

1. Select Prime.

Start a New Feed



If you selected Clear Settings: 1. Select Adjust Rate.



2. Press the + and - buttons to enter the rate, then select OK.





-13°F -25°C

Follow instructions for use. Symbol appears blue on device.

NON

MR Unsafe

Avoid temperature extremes

mycardinalmsds.com

MR Unsafe – an item that is known to pose hazards in all MR environments.

Visit the Kangaroo™ Learning Center at www.mykangaroolearning.com for more information.

ONLY

Cardinal Health 200, LLC

3651 Birchwood Drive Waukegan, IL 60085 USA

Rev. A 2023-03 • cardinalhealth com • HP115204

© 2023 Cardinal Health. All Rights Reserved. CARDINAL HEALTH, the Cardinal Health LOGO, KANGAROO, the Kangaroo LOGO and KANGAROO OMNI are trademarks of Cardinal Health and may be registered in the US and/or in other countries. Patent cardinalhealth.com/patents.

Pause the Feed



1. To suspend the feeding, select Timed Pause



2. To resume feeding, select Resume. Pump will resume on its own after time expires.



1. Press Power button.